

# HYTORC

## TOOL MODEL: EDGE-.5 test 2 PRESSURE/TORQUE CONVERSION CHART

### Standard Torque Chart

PRESSURE IN PSI	TORQUE IN			PRESSURE IN BAR
	FT. LBS.	KGM	NM	
1500	121	17	164	104
1600	129	18	175	110
1800	145	20	197	124
2000	162	22	219	138
2200	179	25	242	152
2400	196	27	265	165
2600	212	29	288	179
2800	229	32	311	193
3000	246	34	333	207
3200	263	36	357	220
3400	280	39	380	234
3600	297	41	403	248
3800	314	43	426	262
4000	331	46	449	276
4200	348	48	472	290
4400	365	50	495	303
4600	382	53	517	317
4800	398	55	540	331
5000	415	57	563	345
5200	432	60	586	358
5400	449	62	609	372
5600	466	64	632	386
5800	483	67	655	400
6000	500	69	678	414
6200	518	72	702	427
6400	535	74	725	441
6600	552	76	748	455
6800	569	79	771	468
7000	586	81	795	482
7200	603	83	818	496
7400	620	86	841	510
7600	637	88	864	524
7800	654	91	887	538
8000	672	93	910	552
8200	689	95	934	565
8400	706	98	957	579
8600	723	100	980	593
8800	740	102	1003	607
9000	757	105	1026	620
9200	774	107	1049	634
9400	790	109	1071	648
9600	806	112	1093	662
9800	823	114	1115	676
10000	839	116	1137	690